



Dual Shade LED Floor Lamp with USB Charging Station

6D200C 6D2G5C 6D200C-SHPR 6D2G5C-SHPR

PL-0094

CONGRATULATIONS!

You've purchased the finest in natural lighting technology with your new OttLite® product.

PRODUCT REGISTRATION FORM

Please complete the enclosed Product Registration Form and return it today by mail, or register online by going to: OttLite.com/warranty

WARNING: To prevent electric shock, make sure the lamp is not plugged in until all assembly steps are complete.

LAMP ASSEMBLY

1. Unpack all lamp parts and lay out with the Base (A) lying flat on a steady surface.
2. The adjustable stand attachment (L) should be placed aside to be installed after assembling floor lamp. SEE ADJUSTABLE STAND ATTACHMENT ASSEMBLY section for proper installation instructions.
3. To ease assembly, straighten flex-neck (C) so that neck and dual shade (D) are in a straight line.
4. Remove wrench (G), bolt (H) and washers (J, K) from the plastic bag included in the box containing the base.
NOTE: On occasions, washers (J, K) may be ONE solid washer that will serve the same purpose.
5. Firmly insert the pole (B) into the hole located in the base (A).
6. Insert bolt (H) through the lock washer (J), then through flat washer (K), and finally into the recessed hole in the bottom of the base (A) as shown in **Figure 1**.
7. Use the enclosed wrench (G) to tighten the bolt (H) securely, turning clockwise until tight.
8. Connect the A/C adapter input (N) into connector (P) located in the rear-bottom of pole (B).

OPERATION

1. Plug the A/C Adapter (M) into a standard household 120V AC outlet.
NOTE: Only use with supplied AC adapter to avoid damage or fire.
2. Turn the lamp ON & OFF by using power switch (E) located in the front-lower side of flex-neck assembly (C). Power switch (E) is a "touch" switch that controls the dimmer function for 4 levels of brightness.
3. To power LED settings, slightly touch the switch (E) to achieve the following:
 - turn lamp "ON" to 1st brightness setting; touch the switch "once"
 - for 2nd brightness setting; touch the switch "two-times"
 - for 3rd brightness setting; touch the switch "three-times"
 - for 4th brightness setting; touch the switch "four-times"
 - to turn lamp "OFF"; touch the switch "five-times".
4. To position the shade simply bend the flex-neck (C) as needed to point the light. To avoid damaging the lamp, DO NOT force the flex-neck into a sharp bend.
5. Dual shades (D) each have a LED light panel for multiple ways to position light.

SAFETY WARNING: TO REDUCE THE RISK OF FIRE, ELECTRIC SHOCK, OR INJURY TO PERSONS

1. Turn lamp off and **WAIT UNTIL LAMP HEADS (D) ARE COOL** before handling.
2. The LED panels (Q) might get hot after several hours of continuous use, **DO NOT** place your hands directly on LED light panels.
3. Never use with an extension cord unless the plug can be fully inserted into the receptacles in the extension cord.
4. Do not alter the plug.
5. The lamp heads included with this unit cannot be replaced by the consumer.
6. **INDOOR USE ONLY.**

NOTE: The important safety instructions appearing in this instruction sheet are not meant to cover all possible conditions and situations that may occur. It must be understood that common sense, caution, and care must be used with any electrical product.

ADJUSTABLE STAND ATTACHMENT ASSEMBLY

1. The following items should be included in the package. See **Figure 2**.
 - L. Adjustable stand (clamp (U) already assembled).
 - S. Screw-bolt
 - T. Tension knob

2. Removed tension knob (T) and screw-bolt (S) already installed on clamp (U).
3. Attach clamp (U) onto front side of pole (B) beneath panel containing touch switch (E) and USB port (F).
4. Spread clamp (U) just enough to fit over the pole, as shown in Figure 2.
5. Insert screw-bolt (S) into clamp (U) from the same side it was removed as shown in Figure 2.
6. Thread tension knob (T) onto the screw-bolt (S) then tighten firmly by hand.
NOTE: DO NOT over tighten tension knob as this may damage it.
7. The adjustable stand is now ready for use. See Figure 3 for proper placement of tablet or other materials.

CAUTION: The maximum loading on the adjustable stand (L) is 2 pounds. Overloading the adjustable stand may damage the stand assembly.

CAUTION: Tray angle is stationary, do not attempt to tilt forward or backwards. See Figure 4

CAUTION! IF THE EXTERNAL FLEXIBLE CABLE OR CORD OF THIS LUMINAIRE IS DAMAGED, IT SHALL BE EXCLUSIVELY REPLACED BY THE MANUFACTURER OR ITS SERVICE AGENT OR A SIMILAR QUALIFIED PERSON IN ORDER TO AVOID A HAZARD.

CAUTION! THE LIGHT SOURCE OF THIS LUMINAIRE IS NOT REPLACEABLE; WHEN THE LIGHT SOURCE REACHES ITS END OF LIFE THE WHOLE LUMINAIRE SHALL BE REPLACED.

FCC PART 15

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that the interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that of the receiver.
- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

CAUTION: Any change or modification to product not expressly recognized by OttLite Technologies voids OttLite's responsibility for proper function of product.

CAN ICES-005 (B)/ NMB-005 (B)

AC/DC ADAPTER

Input: AC 100-240V, 50/60 Hz, 1.4A
Output: 18V DC, 1.3A with a Male DC Plug

THIS LAMP CONTAINS A 5V-2.1A USB output port (F) located in the front-lower side of flex-neck assembly (C), beneath power switch (E).